

Charm Bracelet with Creative Metal

Designed by Sue Kelsey for Walnut Hollow®



Materials:

- [Walnut Hollow® #27996, Beginner Set](#)
- [Walnut Hollow® #29027, Aluminum Metal Square](#)
- Eberhard Faber Fimo®: soft lime green, plum, peppermint, purple violet, black
- Sculpey® Premo: Black, green, blue, purple
- Jewelry Essentials™: 2" head pins
- Fiskars® Punch: Sunburst
- Darice Mirrors
- Inksentials™: Matt Accents™
- Charm bracelet
- Clay Extruder
- Note: Items used below, but not listed in supplies, are included in Beginner Kit.

Instructions:

1. Place a 4 x 4" metal sheet on the 5 x 7" foam matt. Decorate the 4 x 4" piece of metal using any Point attached to the Handle to create texture.
2. Using small Sunburst punch, cut out several designs from the metal and set aside.
3. Roll out the peppermint clay ¼" thick; cut out several circles ¾" diameter. Place the Sunburst designs on each side of the clay circle, pressing firmly. Hold between your thumb and finger and decorate the edge with any Point attached to the Handle to create texture. Insert 2" head pin.
4. Roll black clay ¼" thick; cut out several triangles. Decorate both sides with texture using any Point attached to the Handle. Rollout lime green clay 1/16" thick and cut strips ¼" wide. Wrap around the outside edge of the triangle. Insert 2" head pin.
5. Rollout black clay ¼" thick and cut out several squares slightly larger than the mirrors. Press the tiny mirrors into the clay, fixing the edges to make them square again. Decorate the back of the bead with texture using any Point attached to the Handle.
6. Rollout purple violet clay 1/16" thick; cut into strips ¼" wide. Wrap strips around the edge of a bead. Add texture to the clay using any Point attached to the Handle. Insert 2" head pin.
7. Cut out several triangles with a base ¾" wide by 2 ½" long. Rollout purple violet clay 1/16" thick. Place the metal on the clay. Cut clay even with the metal piece. Place the 2" head pin across wide end and roll to the narrow end with the metal on the outside. Place a tiny ball of clay at the end of the metal to secure the metal.
8. Extrude extra clay in different shapes (circles and squares) and place on head pin. You will use these for beads after baking. Slice with sharp blade into beads.
9. Bake all the pieces according to package directions.
10. When clay is cool; brush with Matt Accents. Let dry.
11. Using the metal head pins, attach charms to bracelet.