



Embossed Metal Trunk

By Rebekah Meier for Walnut Hollow®

Materials:

- [Walnut Hollow® Ballfoot Lancaster Trunk-Small #27710](#)
- [Walnut Hollow® Creative Metal™ Beginner Kit #27996](#)
- [Walnut Hollow® Creative Metal™ Metal Roll, Lt. Aluminum – 2 Sheets](#)
- [Walnut Hollow® Creative Metal Design Borders A & B #28076 & #28077](#)
- [Walnut Hollow® Creative Acrylic Mat #28009](#)
- Silver Spray or Brush on Metallic Paint
- Other Supplies: blue painter's tape

Instructions:

1. In a well ventilated area, spray Small Ballfoot Trunk with silver color spray paint or brush-on-metallic paint. Let dry.
2. Use scissors to cut Aluminum Metal Strips the same size as the front, back and each side of Trunk.
3. Use scissors to cut one piece of Aluminum Metal slightly smaller than the top of Ballfoot Trunk.
4. Use blue painter's tape or masking tape to hold cut Aluminum Metal strips for front, back and top onto Design Border. Using the Texture Tool in the center of the metal, rub over the Metal to reveal the design image. Continue rubbing until the entire image is visible.
5. To refine the embossed image, flip the Metal over and place on the Acrylic Mat. Attach the Nylon Detailer and Nylon Universal Point onto Handle. Use both Points to refine and define the image. The Metal can be turned back and forth on the Acrylic Mat, embossing and debossing the image until the desired effect is achieved.
6. Attach the Square Point onto Handle. Lay Metal onto Foam Mat. Impress Square Point on an angle onto Metal creating a diamond design.
7. Attach Medium Ball Point onto Handle and impress onto Metal. Refine ball design by attaching Medium Cup to Handle and impressing onto ball design.
8. To decorate side portions of Ballfoot Trunk Metal pieces, attach Medium Roller onto Handle. Create an X design onto Metal using the Medium Roller.
9. Using the Nylon Detailer Point, create a "doodle" design between the X's.
10. Finish edges of all Metal pieces using a Medium Roller Point.
11. To adhere embossed Metal onto Trunk, use Metal Tape. Cut Tape into pieces that are the same length as each edge. Affix Tape to back of each Metal piece, remove backing from Tape and press onto the Trunk.



WALNUT HOLLOW