



Metal Flower Frame

By Janet Wilhelm for Walnut Hollow®

Materials:

- [Walnut Hollow® #27755 Wood Frame – Medium](#)
- Walnut Hollow® #28811 Roller Set A
- [Walnut Hollow® Metal Roll, Aluminum](#)
- [Walnut Hollow® Metal Roll, Brass](#)
- [Walnut Hollow® #28016 Metal Tape](#)
- [Walnut Hollow® #28009 Acrylic Mat/Foam Mat](#)
- McGill® Flower Punch #64004 Buttercup
- Other Supplies: Acrylic paint, paint brush, paper towel, Phillips Screwdriver, photo, sandpaper, scissors, spray varnish

Instructions:

1. Use screwdriver to remove tabs that secure frame stand to frame. Remove glass.
2. To prepare frame for painting, use sandpaper to lightly sand wood surface. Remove dust with paper towel.
3. Use paint brush to apply paint to wood surface. Let dry and apply second coat if needed.
4. Apply 2-3 coats of spray varnish for a protective finish.
5. Use scissors to cut (2) 1 ½" x 9 ¾" and (2) 1 ½" x 5" Brass Metal pieces.
6. Use Rollers from Mini Tool Set to create a variety of roller designs on each strip. Place Metal on Foam Mat. Attach desired Roller to Handle and roll over metal.
7. Use McGill Buttercup Punch to punch (4) flower designs from Aluminum Metal. Place flower designs on Foam Mat and create a design with variety of rollers.
8. Use Metal Tape to adhere metal strips to frame. Use scissors to cut Metal Tape to fit on back of metal. Press in place. Remove backing and press metal onto frame.
9. Use Metal Tape to adhere flower designs to each corner of frame. Cut Metal Tape to fit back of flowers. Remove backing and press into place.
10. Turn frame over to replace glass. Lay photo on glass. Place frame stand over photo. Use screwdriver to secure tabs to frame.



WALNUT HOLLOW