

Wood Framed Stamped Box

Designed by Janet Wilhelm for Walnut Hollow®



Materials:

- [Walnut Hollow® #24414 Creative Woodburner® Detailer](#)
- [Walnut Hollow® #5594 Shading Point](#)
- [Walnut Hollow® #27770 Wood Frame Box](#)
- [Walnut Hollow® #9912 Oil Colored Pencils-12 Color Set](#)
- Decorative Stamps
- Ink Stamp Pad
- (2) Photos 3"x 4 1/8"
- Other Supplies: paper towel, pliers, Q-tip, sandpaper, spray varnish, tape

Instructions:

1. To prepare wood, remove frame backing and glass. Set aside until box is complete. Use sandpaper to lightly sand entire wood surface. Remove dust with paper towel.
2. Use decorative stamps to create design on base of box. Apply ink to stamp. Press stamp onto wood. Let dry.
3. Before using hot tool, read through and follow all safety precautions on packaging. Attach Mini-Flow Point to tool. Tighten with pliers. Secure stand to hard surface with tape. Place tool on stand. Plug into electric outlet and heat for 4-5 minutes. Practice on a scrap of wood before beginning project to get a feel for the tool. Use a light touch. Do not press hard, just let the tool do the work and gently glide over the wood.
4. Use Detailer to burn the stamped lines. Hold as if using a pencil. When complete, unplug tool and let cool. Remove Mini-Flow Point. Attach Shading Point, if available, and burn the top of the frames and along the edge of the lid. If the Shading Point is not available, use the Burnt Umber Oil Colored Pencil to darken the areas mentioned. If Shading Point was used, unplug tool and let cool.
5. Use Oil Colored Pencils to add color to the stamped woodburned design. Use Q-tip to blend colors.
6. Apply 2-3 coats of spray varnish for a protective finish.
7. Replace glass, insert photos and replace frame backing.



WALNUT HOLLOW