

Quilt Compression Rack

By Janet Wilhelm for Walnut Hollow®



Materials:

- [Walnut Hollow® #26716 Quilt Compression Rack – 36"](#)
- Honey Maple Stain
- Other Supplies: foam brush, brush, paper towel, sandpaper, wood sealer, spray or brush on varnish

Instructions:

1. To prepare wood for staining, remove screws on back of Compression Rack to separate the two pieces. Apply wood sealer to entire surface. Let dry. Use sandpaper to lightly sand to a smooth surface. Remove dust with paper towel.
2. To apply stain, follow precautions and directions for use on container. Use foam brush to apply stain to wood surface. Remove excess stain with paper towel. Let dry.
3. Apply 2-3 coats of brush on or spray varnish for a protective finish. Between coats, let dry and use a piece of brown paper bag or a piece of cardboard to lightly sand wood. Remove dust with paper towel or soft cloth.



WALNUT HOLLOW